

General Warranty Conditions

The warranty applies to the original purchaser from the date of purchase and covers manufacturing faults and defects only. If an item should fail as a result of a manufacturing fault or defect under normal domestic use, the manufacturer at their discretion will repair, refinish or replace the failed item.

The manufacturer reserves the right to substitute failed items with a similar product should the model or colour no longer be available. Any replacement will be for the failed item only, not a complete set. The original warranty period is not extended in the event of a repair, refinish or replacements.

In the event of a failure, it is the customer's responsibility to return the item to the store of purchase along with a copy of the receipt. LG Outdoor will confirm that the customer has registered their warranty. Warranty specifically excludes general wear and tear, rusting of steel components and parts, corrosion, commercial use and damage caused as a result of failure to observe reasonable care, maintenance and assembly instructions for both furniture and hardware.

This product comes with a Limited Warranty which covers the following:

* 3 Year Limited Warranty - Aluminium Frames - which excludes damage to the finish caused by corrosion, scratching, pitting, fading or oxidisation

* 3 Year Limited Warranty - Texteline and Advanced Texteline - which excludes stains, mildew, fading and stretching of fabric

For all other components not covered by the above a standard 12-month warranty will apply

To register your warranty please visit lgoutdoor.co.uk/furniture-warranty within 28 days of purchase

LEISUREGROW

Dewmead Farm
New Inn Road
Hinworth
SG7 5HG
salessupport@leisuregrow.com



ASSEMBLY AND CARE INSTRUCTIONS

Turin Sunlounger



**This is an important document.
Please retain for future reference.
Please keep your receipt of purchase. Please note we are unable
to process any warranty claim without proof of purchase.**

Care Instructions

- Please keep sunlounger and any cushions away from sources of extreme heat and naked flames
- Do not stand on this product
- Only recline on this product in the way it is designed. This product is only designed to be used with all four feet touching the ground
- Do not sit on the reclining section of the sunlounger, this could damage the product or cause it to tip
- We recommend cleaning this product periodically with warm, soapy water and a cloth or non-abrasive brush. Do not use harsh or abrasive chemicals.
- STAINSAFE Cushions should be cleaned with water only as detergents can weaken the stain-resistant coating. If detergents are used please retreat the affected area with a fabric protection spray.
- To keep your product looking its best, we would always recommend covering with an LG Outdoor Furniture Cover when not being used for longer periods. Throughout the winter months either bring indoors or cover as above. Failure to do so may invalidate your warranty


Necessary Tools Supplied




You will find a pack within this box tied to a red ribbon which contains the fittings.

WARNING – the fittings pack contains **SMALL ITEMS** which are a potential choking hazard and should be kept away from children at all times.


Assembly Requirements

Number of people required to assemble	
Approximate Assembly time	30 minutes





















Read this leaflet in full before commencing assembly.

Step 2



PLEASE ENSURE ALL FIXINGS ARE LEFT LOOSE DURING ASSEMBLY BUT ARE SECURELY TIGHTENED UPON COMPLETION.

Part List Supplied

Ref	Part	Image	Qty	Ref	Part	Image	Qty
A	SEAT		1	J	NUT(M8)		2
B	BACK		1	K	NUT(M6)		2
C	WHEEL		2	L	PLASTIC BOLT CAP		2
D	BOLT (M6*40)		2	M	PLASTIC NUT CAP(M8)		2
E	BOLT (M8*60)		2	N	PLASTIC NUT CAP(M6)		2
F	METAL WASHER(D8.5)		4	O	WHEEL CAP		2
G	METAL WASHER (D6)		4	P	ALLEN KEY		1
H	PLASTIC WASHER(BIG)		2	Q	SPANNER		1
I	PLASTIC WASHER (SMALL)		2	R	TOUCH UP PAINT		1

Assembly Instructions

Step 1

