Hartman

# **Assembly Instructions**

## Asher 2 Seat Sofa

(Product Codes: 69008018)

### PLEASE RETAIN THIS DOCUMENT ALONG WITH YOUR PROOF OF PURCHASE FOR FUTURE

Congratulations on your recent purchase of your beautiful Hartman furniture. We hope it brings you bountiful special moments with friends and family for many years to come. Please follow these simple steps to build your furniture. We also have a very useful video available online to assist with the assembly, please visit <u>www.hartmanuk.com</u>


## TOP TIPS

- Please read these instructions carefully before assembly, for further assistance please view our assembly video online for an easy step by step demonstration
- Aluminum is a soft metal and over tightening may strip the thread or break the part, please loosely assembly your furniture before tightening to secure.
- Please **do not** use power tools, please use the allen key provided in the bolt pack
- Please allow 5 minutes for assembly
- This furniture can be assembled with **2** persons; however, you may need someone to assist you when turning the furniture over into position.

## PARTS LIST

| Components |               |              |     | Fixings    |               |                       |                          |     |         |
|------------|---------------|--------------|-----|------------|---------------|-----------------------|--------------------------|-----|---------|
| Parts List | Parts Picture | Description  | Qty | Part no    | Parts<br>List | Parts Picture         | Description              | Qty | Part no |
| A          |               | Seat Frame   | 1   | 69008018A  | G             | 0                     | Washer<br>(M6*φ16)       | 7   | 1061162 |
| В          |               | Armrest1     | 1   | 69008018B  | Н             | (111111111111111111)) | Bolt<br>(M6X35)          | 7   | 1111162 |
| С          |               | Armrest2     | 1   | 69008018C  | I             | 0                     | Plastic bolt cap<br>(M6) | 9   | 1061163 |
| D          |               | Back Rest    | 1   | 69008018D  | J             | ſ                     | Allen<br>(M6)            | 1   | 1010162 |
| E          |               | Back cushion | 2   | 5AHBC001MG | К             | aaaaaaa())            | Bolt<br>(M6X55)          | 2   | 1644462 |
| F          |               | Seat cushion | 2   | 5AHSC001MG | L             | 0                     | Washer<br>(M6*φ12)       | 2   | 1241162 |


#### STEP 1 & 2: ARMREST ASSEMBLY




**STEP 1:** Attach Armrest 1 (B) to the Seat frame (A) using the M6x35 Bolt (H) and Washer (G)

STEP 2: Repeat step 1 with Armrest 2 (C)

### STEP 3 & 4: BACKREST ASSEMBLY




**STEP 3:** Attach Back Rest (D) to the Seat board(A) using the M6x35 Bolt (H) and Washer (G)



**STEP 4:** Attach the Back Rest (D) to Armrest1 (B) & Armrest 2 (C) using the M6x55 Bolt (K) and Washer (L)

### **STEP 5: TIGHTENING AND FINISHING**



**STEP 5:** Tighten all the bolts on the sofa and cover with the Plastic bolt cap (I). Turn the sofa over and place the Seat cushion (F) and the Back cushion (E) onto the sofa

Hartman

# **Assembly Instructions**

## Asher Lounge Chair

(Product Codes: 69006018 / 69006118)

PLEASE RETAIN THIS DOCUMENT ALONG WITH YOUR PROOF OF PURCHASE FOR FUTURE

Congratulations on your recent purchase of your beautiful Hartman furniture. We hope it brings you bountiful special moments with friends and family for many years to come. Please follow these simple steps to build your furniture. We also have a very useful video available online to assist with the assembly, please visit <u>www.hartmanuk.com</u>


## TOP TIPS

- Please read these instructions carefully before assembly, for further assistance please view our assembly video online for an easy step by step demonstration
- Aluminum is a soft metal and over tightening may strip the thread or break the part, please loosely assembly your furniture before tightening to secure.
- Please **do not** use power tools, please use the allen key provided in the bolt pack
- Please allow 5 minutes for assembly
- This furniture can be assembled with **2** persons; however, you may need someone to assist you when turning the furniture over into position.

## PARTS LIST

| Components |               |              |     |                        | Fixings       |   |                          |     |         |  |
|------------|---------------|--------------|-----|------------------------|---------------|---|--------------------------|-----|---------|--|
| Parts List | Parts Picture | Description  | Qty | Part no                | Parts<br>List | Parts Picture                           | Description              | Qty | Part no |  |
| A          | <u>HHH</u> H  | Seat Frame   | 1   | 69006018A<br>69006118A | G             | $\bigcirc$                              | Washer<br>(M6*φ16)       | 6   | 1061162 |  |
| В          |               | Armrest1     | 1   | 69006018B<br>69006118B | Н             | (111111111111111111)))                  | Bolt<br>(M6X35)          | 6   | 1111162 |  |
| С          |               | Armrest2     | 1   | 69006018C<br>69006118C | I             | 0                                       | Plastic bolt cap<br>(M6) | 8   | 1061163 |  |
| D          |               | Back Rest    | 1   | 69006018D<br>69006118D | J             | ſ                                       | Allen<br>(M6)            | 1   | 1010162 |  |
| E          |               | Back cushion | 1   | 5AHBC001MG             | К             | (11111111111111111111111111111111111111 | Bolt<br>(M6X55)          | 2   | 1641162 |  |
| F          |               | Seat cushion | 1   | 5AHSC001MG             | L             | 0                                       | Washer<br>(M6*φ12)       | 2   | 1241162 |  |


#### STEP 1 & 2: ARMREST ASSEMBLY




**STEP 1:** Attach Armrest 1 (B) to the Seat Frame (A) using the M6x35 Bolt (H) and Washer (G)

STEP 2: Repeat step 1 with Armrest 2 (C)

### STEP 3 & 4: BACKREST ASSEMBLY




**STEP 3:** Attach Back Rest (D) to the Seat Frame (A) using the M6x35 Bolt (H) and Washer (G)



**STEP 4:** Attach the Back Rest (D) to Armrest 1 (B) & Armrest 2 (C) using the M6x55 Bolt (K) and Washer (L)

#### **STEP 5: TIGHTENING AND FINISHING**



**STEP 5:** Tighten all the bolts on the sofa and cover with the Plastic bolt cap (I). Turn the sofa over and place the Seat cushion (F) and the Back cushion (E) onto the sofa

Hartman

# **Assembly Instructions**

## Asher Small Rectangular Coffee Table

(Product Codes: 69007018)

PLEASE RETAIN THIS DOCUMENT ALONG WITH YOUR PROOF OF PURCHASE FOR FUTURE

Congratulations on your recent purchase of your beautiful Hartman furniture. We hope it brings you bountiful special moments with friends and family for many years to come. Please follow these simple steps to build your furniture. We also have a very useful video available online to assist with the assembly, please visit <u>www.hartmanuk.com</u>


## TOP TIPS

- Please read these instructions carefully before assembly, for further assistance please view our assembly video online for an easy step by step demonstration
- Aluminum is a soft metal and over tightening may strip the thread or break the part, please loosely assembly your furniture before tightening to secure.
- Please **do not** use power tools, please use the allen key provided in the bolt pack
- Please allow 5 minutes for assembly
- This furniture can be assembled with **2** persons; however, you may need someone to assist you when turning the furniture over into position.


## **PARTS LIST**

| Components |               |             |     |           | Fixings    |               |                          |     |         |  |
|------------|---------------|-------------|-----|-----------|------------|---------------|--------------------------|-----|---------|--|
| Parts List | Parts Picture | Description | Qty | Part no   | Parts List | Parts Picture | Description              | Qty | Part no |  |
| A          |               | Leg         | 2   | 69007018A | С          | 0             | Washer<br>(M6)           | 12  | 1061162 |  |
| В          |               | Table top   | 1   | 69007018B | D          |               | Bolt<br>(M6X40)          | 4   | 1121162 |  |
|            |               |             |     |           | E          | ۲             | Bolt<br>(M6X15)          | 8   | 1011162 |  |
|            |               |             |     |           | F          |               | Allen<br>(M6)            | 1   | 1010162 |  |
|            |               |             |     |           | G          | Θ             | Plastic bolt cap<br>(M6) | 12  | 1061163 |  |

#### STEP 1 & 2: LEG ASSEMBLY




**STEP 1:** Attach Leg (A) to the Table top (B). At the long side of Table top, using the M6x15 Bolt (E) and Washer (C)



STEP 2: At the short side of Table top using the M6x40 Bolt (D) and Washer (C)

#### **STEP 3: TIGHTENING AND FINISHING**



**STEP 3:** Tighten all the bolts on the coffee table,and cover with the Plastic bolt cap (G). Turn the table over.

